

Orbital Rotating Bath Seat Step-by-Step Cleaning Guide


Follow the steps to clean your Orbital Bath Seat. We recommend you wipe down the bath seat after every use and clean the inside once a month to avoid a build up of mould.

Should you require further assistance:
Scan the QR code for our online
instruction video or:

Contact our Customer Service Team:

☎ 01579208200 10am to 4pm

✉ info@babydam.com





1





Push the release clip on the armrest and lift off for access to clean. When removed reverse the process and push down clicking the armrest back in place making sure it is safely secured.

2



Disassemble your Orbital Seat for a deep hygienic clean by removing the centre screw, then align the outer holes with the outer screws in order to remove the five screws.

3



The rotational sections are now detached from the main body. Press the four push clips and release them one by one. The two sections are then separated.

Clean as required.

4



To reassemble, make certain that the four push fit clips are securely back in place and the two sections are secured together. Refit the five outer screws followed by the centre screw.

Your Orbital Bath Seat is now reassembled and ready for use.



for conscious parenting